



SYNERGY MFG. 870 INDUSTRIAL WAY, SAN LUIS OBISPO, CA (805) 242-0397

4012 JK SPARE TIRE RELOCATION BRACKET

Version 2

GENERAL NOTES:

- The Synergy JK spare tire relocation bracket will move the tire up 1" and away from the tail gate 1 1/4". This is necessary when using a larger spare tire or using less offset wheels than stock.
- The 3rd brake light may be obstructed since the tire is moved up and a larger spare tire is often used.

1. Remove the spare tire.
2. Position the new spare tire relocation bracket over the 3 studs that attach the spare tire. Using the supplied nylock nuts and washers, secure the spare tire relocation bracket, torque the nuts to 75 ft-lbs.
3. Mount the spare tire to the spare tire relocation bracket using the original lug nuts. Torque the lug nuts to 75 ft-lbs.
4. If you are using different lug nuts than stock or a wheel lock nut, make sure that the stud does not bottom out in the nut.
5. Installation Complete.